

SHOTSHELL HOLDER

A revolutionary system, our Shotshell Pouches provide fast drawing of all 4 shotshells at the same time for fast reloading of the shotgun. The rotating clip can be positioned by the shooters preference. Changing the position of the shotshell clips can be done by the allen screws. Available only for 12 gauge shotshells.



SHOTSHELL HOLDER PRO

A revolutionary system shotshell pouch, the Shotshell Holder Pro provides fast drawing of 2/4 shotshells at the same time for fast reloading of the shotgun. As the springs are made of hardened metal, the retention doesn't change. The rotating clip can be positioned by the shooter individually.



PRO8 holds up to 8 shotshells in the same holder to reduce the space on the belt.

cod. SGHSSP8

cod. SGDHSSP8 (dervet system)



ADJUSTABLE RETENTION SYSTEM BY SCREWS

Rifle magazine pouches are made from ABS which is a high impact resistant polymer. It includes a rotating clip for adjusting to the desired position. Adjustable retention by four screws on both sides of the pouch hold the magazine firmly in place.

Available for AR15 or AK47.

- cod. SGMAG15 (AR15 magazines)
- cod. SGDMAG15 (AR15 magazines with dervet system)
- cod. SGMAG47 (AK47 magazines)
- cod. SGDMAG47 (AK47 magazines with dervet system)

GH SPORT RIFLE MAGAZINE POUCH

Sport rifle magazine pouches L are made from ABS which is a high impact resistant polymer. Complete with a rotating clip for adjusting the angle and a low-ride belt attachment. This guarantees a very fast and comfortable draw. These pouches are ideal for longer magazines and seated or kneeling shooting positions. Adjustable retention by four screws on both sides of the pouch to hold the magazine firmly in place.

Available for AR15 or AK47.

- cod. SGMAG15L (AR15 magazines)
- cod. SGMAG47L (AK47 magazines)



WARNING! READ THE FOLLOWING BEFORE USING AMADINI GHOST HOLSTER

- Use of handgun under any condition may be dangerous
- Great care should be used when placing or removing a handgun from its holster
- Never place a loaded handgun in a holster without first unloading the handgun to test for proper fit.
- Carrying any handgun with a live cartridge in the chamber cause an accidental discharge
- Cocking the handgun while holstered may cause accidental discharge and is not recommended.
- Particular modifications to the weapon , such as the use of trigger shoes or grip adapters, may change the position of the handgun in the holster and render an unsafe and extremely dangerous condition and is not recommended.
- Any alteration to a AMADINI Ghost Holster holsters or using a gun for which it was not made could also cause dangerous condition and is not recommended.
- It is also the users responsibility to regularly check the holster and its hardware. Should it become defective, broken, or worn, discontinue use immediately
- Your holster may have some tension screw adjustments that we recommend you check and adjust before each use
- Please be certain that your handgun fits properly in its holster to help assure no movement occurs
- Keep thumb on back of hammer or slide when inserting a handgun in its holster to help assure no movement occurs.
- Keep fingers clear trigger when drawing or replacing handgun in holster
- During physical activity the gun should be held in place with your hand to prevent it from dropping

AMADINI GHOST HOLSTER reserves every right to introduce any modification to its items for improvement or order trade purpose without notice.

No returns will be accepted without prior factory authorization.

Limited Warranty and Maintenance: All the Amadini GHOST products have a limited two years warranty against material or manufacturing defects from the date of purchase. The Warranty does not apply to normal wear and tear, misuse or failure. Please read and follow the products' instructions and warnings. SPORT HOLSTERS don't need any maintenance.



**SPORT
MAG POUCHES**



*Leggere attentamente le istruzioni prima dell' uso.
Read instruction booklet carefully and completely before use.*

This magazine pouch is made from virtually indestructible ABS and can be used by both right and left-handed shooters. The pouch is made for double stack magazines. It will fit all types and brands. The pouch can be rotated in any angle you desire.

To lock in position, remove the clip the clip-spring by pressing with a hard object against one of the two hooks of the clip-spring. This will expose a Phillips screw and when tightened it will lock it in that position. Install the clip spring back to its original position. Make sure the spring sits firmly in place.

Included in the package is an extra clip with a rib on it for higher tension if required.

ROTATING CLIP

Thanks to the rotating clip you can find the perfect position for your mag pouch. Compatible with all the belt's types.

How to adjust the clip on your belt:

- Measure your belt's height.
- Unscrew the screws behind the clip.
- Adjust for your belt's size
- Tight the screws.



Single Stack mag pouches. Thanks to the smart design our single stack mag pouches will reduce the space required on the belt.

- Adjustable by allen key
- Internal retention spring
- Rotating speedclip

Single

COD. SGMAG11

DERVET SYSTEM SGDMAG11



GI MAGNETIC POUCH



Magnetic magazine pouch with special Speedclip.

COD. SGMAG1

DERVET SYSTEM SGDMAG1

Magnetic magazine pouch with wings and rotating speedclip: unscrew the magnet to adjust the wings.

COD. SGMAG2

DERVET SYSTEM SGDMAG2



When you have to shoot from a lying or crouching position, most of the time the normal position of your magazines is not sufficient. You now have the possibility to change position of the holder in mere seconds without changing belt or loosening the holder from the belt.

Adjustable for any belt size.

Adjusting the clip to your belt.

- Measure the width of your belt.
- Unscrew the screws at the back of the clip.
- Slide the bottom part of the clip up or down, so you will get the distance of the belt width between these points.
- Tighten the screws.